1. Connect the ‘2-wire adapter’ into the system, USB to PC, BUS port to BUS port(can be connected to any BUS port in the system).

Set the dialer 1 from the back of the OS, 1 on 2 off , then power up the device.

2. Open the software

,

First open the COM port and connect device.

Then choose 2 wire system.（or IP system）

click ’File export’, then you will get an excel file with information as below:

1	Welcome->2 Wire System									
2	ID	Building No.	Floor No.	Apartment No.	Physical	User Name 1(*)	User Name 2	Logic Address	Card No.(*)	User Password(*)
3	0001				00001	פודניץ			2602638,8789486,82282 68,8797813,2654680,263 5191,8226682,8688399,8 177506,8167649,823997 1,2606217,2617378,2615 449,2602156,8683952,81 76486,2594129,2584442, 8801055,8194338,26096 88,8242589,2665498,823 7489,8241993,8671226,8 688410,8169984,264236 0,8781617,2665233,2647 472,2658468,2600167,26 61625,2659104,2610152, 2585003,2639621,26554 64,8241611,2634146,878 3157,8695014,2606252,8 685010,8719183,261767 8,2612415,2648469,2629 930,8182823,2650142,86 88776,2607458,2608411, 2612368,8189699,82395 94,8726893,8198694,260 6154,2618256,2599215,8 165077,8723443,818326 6,8727148,8708560,8701 256,8227942,8169226,81 71288,8167091,8194975, 2626169,8727633,87163 67,2641559,2608041,820 5958,2632285,8164426,2 653070,8222047,264023	123456
4	0002				00002	עמיר				123457
5	0003				00003	בנר				123458
6	0004				00004	סגל				123459
7	0005				00005	שריבר				123460
8	0006				00006	לוי				123461
9	0007				00007	איינגנגדלר/אלב'ם				123462

Remark: You need to input a random User password for each ID when you input the registered cards , just show as the picture, and all cards could type in one user.

3. You can change the user name, or physical address that refers to actual apartment(room no.) with this file.

4. After the modification is done, save the file and import it to the OS by clicking ‘File import’ and ‘Send the configuration’.